



# Ryobi VC120 Battery Replacement

This guide will help you remove and replace your vacuum's battery.

Written By: Allison Schoch



## INTRODUCTION

Use the guide to replace your battery in a few simple steps.

## Step 1 — Battery



- To remove your battery, hold both of the rear buttons down simultaneously and pull backwards on your battery compartment.

---

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-16 10:29:25 AM.